

INFORMATION

WURLITZER

DEUTSCHE WURLITZER GMBH

WERK LEVERN

4995 STEMWEDE 1 · POSTFACH

Telefon (0 57 45) 2 80 · Telefax (0 57 45) 28 20

TI-MA-63

Bedienungsanleitung für Mikrofon-Kit (Art.-Nr. 0006953)

Dieser Kit ist nur verwendbar in Verbindung mit dem Verstärker Art.-Nr. 0002909 (I84, 40200).

Das Mikrofon-Kit wird angeschlossen, indem der 7polige Stecker in die mit MIKROFON bezeichnete Buchse am Verstärker gesteckt wird.

Ist die Musikbox mit einer Lichtorgel ausgerüstet, so ist der dann an dieser Position befindliche Stecker abziehen und in die Kupplung des Kabelbaumes vom Mikrofon-Kit zu stecken.

Bei der Montage des Kits sollte darauf geachtet werden, daß die Leitung möglichst nicht parallel zu einer netzspannungsführenden Leitung verlegt wird.

Wird das Mikrofon mit dem Taster eingeschaltet, so verstummt die Musik (falls eine Platte spielt). Die Ansage ertönt mit der am Bedienungskasten unabhängig einstellbaren Lautstärke.

Das Mikrofon ist erst ca. 1 s nach Drücken der Taste empfindlich, um die bei der Handhabung entstehenden Störgeräusche auszuschalten. Soll bei bestimmten Anwendungen die Musik nicht abgeschaltet, sondern nur um einen festen Wert abgesenkt werden, so muß im Stecker die vom Bedienungskasten kommende Leitung, die an Pol 1 geht, auf Pol 4 umgelötet werden.

(Achtung! Die von der Kupplung kommende Leitung muß an Pol 1 verbleiben).

Operating instructions Microphone Kit (Part-N° 0006953)

This Kit works only in conjunction with an Amplifier Part-N° 0002909 (I84, 40200).

Place microphone and control box where it is required and run the cable towards the phonograph. Avoid running the cable closely along power lines to avoid pick-up of interferences. The length of the cable is 15 Meters; any extension increases the risk of interferences pick-up.

If the additional length required is considerable it might be advisable to replace the entire length of the cable for one which provides a screened lead for the signal line.

Plug the pin-type connector to that plug socket of the amplifier which is marked MIKROFON.

b.w./p.t.o.

If this socket is found to be occupied by a connector of another accessory, pull that plug and insert it into the receptacle-type connector of the mike-kit cable.

Try the microphone by actuating its push-to-talk button and speak; it takes about 1 second's time until the mike is "alive". Set the volume to the required level with the knob of the Control Box. Do not use the microphone in an area directly facing the phonograph speakers, as here the risk of acoustic feed-back (howling) prevails.

The mike kit may be used at any time, whether the phonograph plays a record or is idling. If the phonograph is playing, its music's volume is greatly reduced automatically for the period the push-to-talk button is held.

If a partial reduction of music's volume is preferred instead of the full reduction, this can be arranged by transferring, inside the pin-type connector, the wire found at pin 1 and coming from the control box, to pin 4. That wire at pin 1 which comes from the adjoining receptacle-type connector, has to remain at pin 1.

IV/84 Pa/Ost-Fr
XII/90 Gr-Ze

