

Electronics Division Box 1246 2876 Culver Ave. Dayton, Ohio 45401 Telephone (513) 296-0330

## Operating Instructions For Model 103A

SPACE RACE/ASTROID
Atari/Midway

	SL2				START 2				SR 2			5 V		
LLP	SEI	* \$1,5	SŁ3	LAP	ĸ	X START 1	RLP	SR1	x SA 5	SR3	RRP	ON	OFF	
×	×	× SL4	x	x	x	x	x	. *	x SR4	×	¥			
	SL6	×	<b>\$</b> L7			COIN		\$86	ĸ	\$ <b>8</b> 7		PO	WER	
	х		×			×		×		x	×	ÓN	OFF	

- 1. Insert 103A card into program "A" connector, number side up.
- 2. Insert computer board into test fixture, using 22 pin orientation.
- 3. Turn power switch to on.
- 4. Push coin switch once, credit LED will come on.
- 5. Push coin switch once to start game.
- 6. SL2 controls vertical up movement of left space ship.
  - SL4 controls vertical down movement left of space ship.
  - SR2 controls vertical up movement of right space ship.
  - SR4 controls vertical down movement of right space ship.